

MEGLIO STEAM CLEANER

YOUR
Instruction
Manual



DeLozio

WWW.DELOZIO.COM

OUR Mission

Our mission is to help you achieve and maintain a cleaner, greener, and healthier home.

Offering an eco-friendly cleaning solution proven to eliminate household pollutants, allergens, and 99.999% of enveloped viruses and bacteria on hard surfaces. Designed and produced in Italy, they are well-known for being among the best steam cleaners in the world.

TABLE OF CONTENTS

How to Use your Steam Cleaner 8

Important Safety Instructions 4

Description 6

Technical Specifications 7

Troubleshooting 10

Accessories 12

Maintenance 14

Warranty 16

Important Safety Instructions

WARNING: Please read the following instructions carefully as they provide important information concerning the installation, use, and care for your Meglio steam cleaner.

- Keep this booklet in a safe place for any future reference.
- Use the steam cleaner only for its intended use.
- Remove packaging and make sure the steam cleaner has not been damaged. If in doubt, do not use the appliance and contact us.
- Before plugging the appliance, make sure the data on the voltage rating plate (under the machine) are the same as the main's supply.
- The steam cleaner should always be turned off before unplugging. Never pull the power cord to disconnect from the outlet; instead grasp the plug and pull to disconnect.
- Do not use barefooted.
- Do not leave the steam generator ON while unattended.
- Do not use extensions without safety marks (UL, ETL, etc).
- Do not immerse in water.
- Keep ventilation slots free from dust.
- Do not overfill the water tank.
- To prevent overheating, unravel the electrical cord completely.
- Always make sure the hose does not come in contact with any hot surfaces, steam, oil, sharp edges or get caught in between doors or drawers.
- Do not touch steam or accessory during, or shortly after usage to avoid getting burnt.
- In the event of a breakdown and/or malfunction, switch to off and contact us. Do not try to fix the unit by yourself to prevent voiding the warranty.

- Never put detergent, perfumed substances or any other chemical substances inside the water tank unless they are approved by DeLozio.
- Risk of explosion - Do not spray flammable liquids.
- The handle might get hot during use.
- Keep away from children.
- Store unit indoors only.
- Do not use the steam directly on electrical appliances and sockets.
- To ensure machine safety, use only original spare parts from the manufacturer.
- Do not put away the unit while it is still hot, allow time to cool down.

IMPORTANT WARNING

- Like any other powerful tool, it should be used with caution. Certain surfaces, fabrics, materials and finishes are water and heat sensitive and can be damaged or discolored by steam. If in doubt, always verify with the manufacturer of the surface or product you intend on cleaning. You may also try testing on a small hidden area to make sure the surface can be steamed.
- Do not leave steam cleaning cloth or pad on any surface for a long period of time to avoid any damage.
- Do not use on unsealed wood, tile floors that are highly worn, unfinished or have a wax or oil finish. Surfaces that have been treated with wax or no-wax floors may be damaged by heat.
- Do not use on leather, synthetic fabrics, velvet or other delicate, steam-sensitive materials.
- Do not use this steam cleaner for purposes other than what has been described in the instruction manual.
- In no occurrence will DeLozio be held responsible for incidental or consequential damages to anyone, anything, or of any nature.

Description

Offering a faster, effective and eco-friendly cleaning solution. When used correctly, our machines eliminate household pollutants, allergens, and up to 99.999% of enveloped viruses (such as COVID-19 or influenza), and household bacteria from hard surfaces. Leading to a significant general hygiene improvement in residential, medical, commercial and industrial applications.

Using the unit for any other purpose will be considered as improper and dangerous. Under no circumstances can the manufacturer be held liable for damages arising from any improper, incorrect or unreasonable use.

Use for a large variety of surfaces such as: ceramic, stone and parquet floors, carpets, rugs, wooden ceilings, wallpaper, upholstery, windows, mirrors, sanitary fixtures, taps and fittings, cooking hobs, ovens, grills, refrigerators, freezers, radiators, door and window frames, door jambs, furniture, fireplaces, cars, seats, etc.



COMPONENTS

1. Water tank cap
2. Main power switch
3. Screen Indicator
4. Steam hose socket
5. Electrical Cord
6. Caster wheels

Technical Specifications

SPECIFICATIONS	Meglio 110-120 V
TEMPERATURE	165°C 329°F
PRESSURE	6.5 bar 87 psi
POWER	1750 W
VOLTAGE	110-120 V
AMPERAGE	14 A
DIMENSIONS	12.5 x 13 in.
WEIGHT	6.5 kg 13 lbs
CLEANING TIME	Unlimited
HEATING TIME	6 minutes
BOILER MATERIAL	AISI 304 Stainless Steel
BOILER CAPACITY	1.6 L 0.42 gal.
WATER TANK CAPACITY	1.3 L 0.34 gal.
PRESSURE REGULATION	On the handle
STEAM HOSE LENGTH	2.5 m 8.2 ft
POWER CABLE LENGTH	5 m 16 ft

How to Use Your Steam Cleaner

1

Remove the cap of the water tank and **fill** to a maximum with regular tap water. We recommend adding 3 sprays of the Anticalcare product per liter of water to avoid limescaling. Safely replace the cap. Use a bottle to fill or refill the water tank for an easy spill-free process.

2

Unravel the electrical cord completely and **connect** to the recommended power outlet (indicated underneath the unit). This machine will draw 14 amps of power so make sure your electric circuit isn't used for any other devices.

3

Lift the flap situated on the front of the machine and plug in the hose into it, when properly installed, it will click into place.

4

Press the front control button to start the machine boiler. Wait until the maximum temperature is reached and indicated on the screen.

5

You may now attach the chosen accessory onto the hose, one of the extension tubes (rectangular tool, triangular tool, squeegee tool or steam lance) or onto the steam lance (brushes on extra).



6

Once the maximum temperature is achieved, **you may now choose the steam pressure** level using the two control switches. Press the one-dotted switch for low pressure, the two-dotted switch for medium pressure and both switches for the maximum pressure.

7

In order to **release steam**, press the steam release trigger on the hose handle.

8

Once you are done using your steam cleaner, turn the **unit OFF** by pressing the power button, then unplug. **Let the machine cool down for a minimum of 30 minutes before storing.**

WARNING: Always turn OFF the main power switch when leaving the machine unattended.

9

It is **safe to leave water in the boiler** when the steam cleaner is not in use. If it is for an extended period of time (a few weeks), then it is best to flush out the remaining water. To do so, follow the water removal instructions as outlined in the maintenance and care section.

TROUBLESHOOTING

WARNING: Do not operate the steam cleaner with a damaged electrical cord, plug or if the steam cleaner has been dropped or damaged. To avoid any risk of electrocution, do not disassemble or attempt to repair the unit on your own. Contact our support team to know if you are to return the unit for examination, repair or replacement. All services are to be performed by DeLozio authorized professionals.

PROBLEM



SOLUTION

The machine does not produce steam

- Make sure the plug is inserted correctly in a proper powered outlet.
- Make sure the electric circuit isn't used for any other devices.
- Verify that the main power switch is turned ON.

The low water indicator lights up accompanied of a "beeping" sound

- Add water into the tank.

While operating, a noise is coming from inside the boiler

- Wait until the pressure stabilizes (2-3 minutes), the noise will disappear.

PROBLEM

SOLUTION

Water is leaking from the connections

- Clean and lubricate the o-rings with petroleum jelly. If necessary, replace with the supplied spares.
- After a few minutes of usage, this problem will disappear.

Steam pressure is dropping when in use

- Use a lower pressure setting.

Steam does not come out

- Wait a few minutes.
- Make sure the power switch is ON.
- Select the desired pressure setting by pressing one or both buttons onto the hose handle.



STANDARD ACCESSORIES



STEAM HOSE

This 2.5 meter steam hose is a must for all types of cleanings. Adjust pressure as you wish.



TRIANGULAR TOOL

Wrap a microfiber cloth around the triangular tool to unlock the highest cleaning temperatures.



RECTANGULAR TOOL

Attach a microfiber cloth around this tool to unlock a powerful high temperature floor and wall cleaner. Cleans tiles, carpets and even hardwood floors.



SQUEEGEE TOOL

This tool will leave your windows with a chemical-free and streak-free shine. 10 inches.



MICROFIBER CLOTHS

Superior quality microfiber cloths. Machine washable. 16 x 16 inches (2)

All accessories on pages 12,13, and 14 are included with the purchase of the Meglio steam cleaner.



STEAM LANCE

Our most versatile accessory. This lance tool can be used on its own for precision work, or with a detailing brush for extra scrubbing power.



ANTI-LIMESCALE

Specifically developed to prevent any damage caused by limestone inside our boilers.



EXTENSION TUBES

Steam clean your floors, ceilings, walls and other hard to reach areas with this pair of 19 inch long extension tubes. (2)



SCRAPER TOOL

Great for removing stickers, wallpapers and adhesives. To be attached to the lance.



DRAIN KEY

Use to open the drain to evacuate the water from the machine.

STANDARD ACCESSORIES



POLYESTER BRUSHES

Perfect for a delicate and deep cleaning without being abrasive. Ideal for grout cleaning.
30 MM (1) + 38 MM (1) + 60 MM (1)



BRASS BRUSHES

Ideal for medium duty work where precision is required. 30 MM (1) + 38 MM (1)



STEEL BRUSHES

These steel brushes are best for heavy duty work. Our toughest grade brushes for the toughest jobs.
30 MM (1) + 38 MM (1)

Maintenance and Care

BOILER MAINTENANCE:

To maintain your steam cleaner in good condition and to ensure constant performance, we recommend following the instructions below:

WARNING: Before cleaning the boiler, please ensure that it is at room temperature, that it has not been used for a minimum of 8 hours and that the appliance is unplugged from the power source.

ADD ANTI-LIMESCALE

FREQUENCY: EVERY DAY

Add 3 sprays of anti-limescale when filling the water tank before usage, this will prevent limestone build-up.

DRAIN BOILER

FREQUENCY: EVERY WEEK

Drain the boiler weekly. In order to do so, place the unit above a sink and unscrew the drain plug located on the bottom of the machine. When it is completely empty, replace the drain plug back on and replace the cover.

ADDITIONAL ACCESSORIES



POLYESTER BRUSH

70 X 50 MM



BRASS BRUSH

70 X 50 MM



STEEL BRUSH

70 X 50 MM



DRAIN TOOL

This tool lets you unclog your drain without using chemicals or making a mess.



STEAM MOP

Use this Steam Mop head to clean marble, granite, wood, walls, ceilings or flat surfaces.



MICROFIBER PADS

Ultra-thick microfiber pads designed to fit the Steam Mop. Machine washable. (5)

DESCALE BOILER

FREQUENCY: EVERY 3-6 MONTHS

WARNING: Before proceeding into descaling the boiler, be sure that it has not been used for at least 8 hours, and that it is no longer connected to a power source.

- Empty water tank
- Drain boiler by removing plastic cap and drain nut located under the machine, then put both of them back into place;
- Add 40 grams of tartaric acid into 1L of water;
- Pour the solution into the water tank;
- Plug-in the power cord into wall outlet
- Turn on the machine by pressing the main ON/OFF power switch;
- Add 1L of water into tank;
- Leave the machine ON for 2 hours without generating any steam;
- After two hours, produce steam for a few minutes;
- Turn machine OFF, unplug power cord from outlet and allow it 4 hours to cool down;
- Empty boiler and water tank;
- The device is now ready to use.

Limited Warranty

DELOZIO 3 YEAR LIMITED WARRANTY

DeLozio (Soluvap inc.) hereby warrants that new DeLozio steam cleaners purchased from DeLozio (Soluvap inc.), will be free from factory defects in material and workmanship for the period of time stated below, subject to certain limitations.

WARRANTY POLICY

First year of the warranty covers shipping, parts, and labour. Second and third year of the warranty covers parts but not labour or shipping. This warranty does not cover any consequential damages or business loss. This warranty is NOT transferable.

WARRANTY PERIOD

The limited warranty on your DeLozio steam cleaner is three (3) years from the date of purchase by the original owner against defects in material and workmanship. The warranty on the boiler is valid as long as is it claimed by the original owner.

GENERAL EXCLUSIONS -

General exclusions from this warranty shall include any failures caused by:

- A. Scale from using hard water with high mineral content and/or damage from using water with high chlorine content or omitting to add anti-limescale on a regular basis.
- B. Installation of parts, accessories or attachments or that are not original to the unit or genuine DeLozio parts.
- C. Accident or collision damage.
- D. Lack of proper maintenance.
- E. Abnormal strain, neglect, or abuse.
- F. Changing or altering factory settings without consulting an authorized technician.
- G. Damage or malfunctions resulting from natural calamity, freezing, theft, accident, vandalism, abuse due to misapplication and/or improper site conditions.
- H. Water damage.
- I. Electrical damage from including, but not limited to improper use of extension cords, failure to meet proper voltage requirements, incorrect or insufficient amperage circuit.
- J. Insufficient unobstructed distance on exhaust.
- K. The owner or user neglected to do routine maintenance required and the damages or problems are directly related to such neglect. It is the Client's responsibility to keep equipment in proper condition and to use exclusively DeLozio cleaning products so as to not damage the internal components.

SPECIFIC EXCLUSIONS -

Items not covered under warranty include:

- A. Parts replaced due to normal wear or routine maintenance, including but not limited to sensors, filters, fuses, valves, pipes, electrodes, cables and fittings (e.g. nipples, couplings, o-rings, etc) .
- B. Steam hoses, guns nozzles and other accessories.
- C. Any transportation or travel costs.
- D. Reimbursement for rental units while repairing warranty items.
- E. Normal maintenance items such as: draining tanks and boiler, descaling, cleaning or replacing sensors, replacing filters and fuses, soot removal, tightening and sealing bolts and fittings and others stated in the user manual.
- F. Failure caused by water scale problem due to local water conditions.
- G. Warranty work completed after 30 days from discovery.
- H. Claims made under fraudulent situations.
- I. This warranty does not cover machines used for rental purposes.

CUSTOMER'S RESPONSIBILITY -

Under this warranty, the customer shall:

- A. Operate and maintain the machine as specified in this instruction manual.
- B. Give notice to Delozio of apparent defects within ten (10) days after initial malfunction.
- C. Provide proof of purchase, purchase date, and serial number of the warranty item(s); Some states do not allow limitations or warranty exclusions, so the above limitations or exclusions may not apply to you.

FORCE MAJEURE -

For all purposes hereof, force majeure includes any act of God, war, mobilization, governmental regulation, strike, lockout, drought, flood, total or partial fire, obstruction of navigation, loss, damage or detention in transit, defective materials or delays by shippers, or other contingencies or causes beyond Seller's control which might prevent the manufacturer, shipment or delivery of Goods covered hereby. Performance of Seller's obligations may be suspended pending force majeure, without Seller being responsible to Client for any damages or losses resulting from such suspension.

3-YEAR

Limited Warranty

LIFETIME

Warranty on Boiler

Need Help?

1 844-492-0909

support@delozio.com

WWW.DELOZIO.COM